

Safety Precautions

- Read all safety instructions and installation instructions (read and before packing or leaving the fixture) and comply with these instructions. Failure to follow these instructions could result in electrical shock and/or property damage.
- It is recommended that a qualified electrician perform all wiring. The fixture must be installed in accordance with all national and local electrical codes.
 - Do not touch any wires or electrical components of the fixture with wet hands or while standing on a wet or damp surface or in water.
 - This fixture is designed for use in a 120VAC, 60 Hz household.
 - To reduce the risk of electrical shock, and to ensure proper operation, the fixture must be electrically grounded. To ensure an error grounding there must be a separate ground wire (green) connected between the fixture and the ground connection of your main power supply panel.
 - The fixture is intended to be used for general nuisance lighting in wet locations.
 - Do damage:
 - Warnings: All electrical connections must be performed by the user or a qualified electrician. Failure to follow these instructions could void the user's warranty to service the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules and Canadian ICES 005 (B). These limits are designed to provide reasonable protection against interference with other radio communications. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Any modifications to this fixture may void the warranty and interfere with safe operation of the device. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Assembly Instructions

Step 1 - Preparing for installation.

- Disconnect electrical power at fuse or circuit breaker box before installing or servicing any part of this fixture.
- Carefully remove the fixture from the carton.
- Remove mounting bracket (1) from the parts bag.
- Install mounting bracket (1) on the junction box (not grounded) by securing it with two screws (2).

Wiring all wiring must take place in the junction box (not included).

Warning: Make sure power is off at fuse or circuit breaker box. Check power wires for damage or fraying. Use wire suitable for at least 90°C (194°F). Note: Most dwellings built before 1985 have supply wires rated to 60°C. Consult a qualified electrician before installing.

Step 2 - Wiring fixture.

- Make all wire connections to copper wire. Secure with wire nuts (provided).
- Connect the bare wire from the fixture to the supply power source ground wire.
- The black wire from the fixture is connected to the black (L) wire from supply power source.
- The white wire from the fixture is connected to the white (N) wire from supply power source.
- Tighten all connections inside the junction box.

Step 3 - Color temperature adjustment

Adjust CCT slider to the desired color temperature.

Step 4 - Mounting.

- Slide the back plate (3) over the mounting bracket (1) by aligning holes on pan with screws and fasten with two finish nuts (4).
- After mounting the fixture, seal the crevice between the back plate (3) and the mounting surface to keep water out.

Step 5 - Restore power at fuse or circuit breaker box

