

WARNING

PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION

To avoid electric shock or component damage disconnect power before attempting installation or servicing.

This product must be installed in accordance with the national electric code (NEC) and all applicable federal, state and local

Disconnect product and allow cooling prior to servicing.

Any alteration or modification of this product is expressly forbidden as it may cause serious personal injury, death, property damage and/or product malfunction.

To prevent product malfunction and/or electrical shock this product must be properly grounded.


This luminaire is designed to operate in ambient temperatures ranging from -40°C to 40°C and to be horizontally mounted with th

This product is not available for several special environments, such as places with corrosive gas liquids or high pressure water vapor

SHOCK HAZARD!



To avoid electric shock or component damage disconnect power before attempting installation or servicing.



TOOLS REQUIRED


Tools:

1. Sharp Side Cutter
2. Electric Drill
3. Level
4. Measuring Tool
5. Wire Stripper / Knife
6. Philips Screwdrivers
7. Wire Cutters

WIRING


CORD/ SUOOLY WIRING

LUMINAIRE



Installation Guide

1. Remove the lens from the housing by pressing the provided suction cup to the lens near one end of the luminaire.
Pull up on the suction cup to detach the lens from the luminaire housing.



1. Place the luminaire on the junction box and pencil the four hole positions onto the ceiling. Put the luminaire aside and drill the four holes. Insert an anchoring bolt (not included) into each hole. Screw the four mounting screws into each anchoring bolt, then connect the AC wires.
2. Install the lens, starting at one end of housing. Insert lens slot onto edge of housing. Carefully squeeze the lens to engage opposite side with housing. Continue this action down length of lens until fully installed onto housing.

